


SAGE CINEMA LINE 3 QUICK LOOK WIRING GUIDE



Two pair of speakers wires are needed. One for High-Pass, and one for Low-Pass. You can bring them in to either the top or bottom of the Line 3

Then connect the two modules together using small jumpers



All specifications are subject to change at any time in order to improve the product.

Wisdom Audio | 1572 College Parkway, Suite 164 | Carson City, NV 89706 | 775-887-8850 | information@wisdomaudio.com | www.wisdomaudio.com

© 2019 Wisdom Audio Corporation. All rights reserved. Wisdom and the Wisdom logo are registered trademarks of Wisdom Audio